

---

**PRODUCT SPECIFICATIONS**

---

**Product: P-D Cleaner**

---

**Description:** P-D Cleaner is a concentrated developer tank cleaner. Ecological approved. No toxic ingredients.

**Applications:** Used for all Specialty Products developer tanks, especially designed for Silver deposit removal.

**Used in combination with:** Developers PDEV and all other developers for silver holding film developers.

**Using conditions:** Dilution: 2.5 liter A and 2.5 liter B for 15 to 20 liters of tank capacity. Working temperature: 35°C / 95°F

**Storage conditions:** Always store P-D Cleaner in a frost-free environment. Damage to the chemistry will result if it has been frozen.

**Disposing** P-D Cleaner can be disposed together with the waste fixer.

**Shelf life:** 30 months after manufacturing.

**Sales packaging:**

Chemistry	ABC code	Packaging	dilution
P-D Cleaner	<b>P38FS</b>	3 x 2.5 l. bottle A 3 x 2.5 l. bottle B	2.5 l A + 2.5 l B makes 15 - 20 liters

**Precautions:** avoid contact with skin. After contact, rinse thoroughly with water.

**User instructions:**

1. Empty the dirty developer tank and rinse with a little water.
2. Leave the rack in the tank and fill the tank with 2.5 liter part A, 10 liter water and 2.5 liter part B per 15 to 20 liters of tank capacity.  
Top with water.
3. Let the processor run for 30 to 60 minutes at the normal working temperature (min. 35°C).
4. Drain the solution into the waste fixer.
5. Rinse sincerely and close the tank.
6. Fill the tank with tap water and let run for 5 minutes.
7. Empty the tank in the waste fixer..
8. Rinse carefully, make the circulation pump run for a minute or so.
9. Repeat step 6 once more. If not you risk to damage the developer when refilling.
- 10 Refill the developer.